



**Installation Instructions:**

1. Remove the lock from the door.
2. Install the adapter plate between the lock and the door.

---

**Instrucciones de instalación:**

1. Remueva la cerradura de la puerta.
2. Instale el adaptador entre la cerradura y la puerta.

---

Pro-Lok® And Entry Armor® Are Trademarks Of Weinraub Enterprises, Inc. © 2010. [www.ENTRYARMOR.com](http://www.ENTRYARMOR.com)

Item # EAP-110-C



6 38246 31128 6



**EAP-110-B**

UPC: 638246311279



**EAP-110-C**

UPC: 638246311286